

Instructions for Use



PURPOSE

This mat is designed to control contamination in sensitive environments. Proper use ensures **a longer lifespan** and **maintains its protective function**. Misuse can lead to damage and reduced effectiveness.

BEFORE USE

- Place the mat on **a clean, stable floor**.
- If the floor is slippery or unstable, consider using **the version with removable antibacterial adhesive backing**.
- When unboxing, **unroll the mat in reverse** to help it regain its original shape.

CLEANING PROCEDURE

We recommend using **our cleaning products** or those approved by your facility.

1. Spray the entire surface and let it sit for a few minutes.
 2. Use a sponge squeegee to loosen and lift contaminants.
 3. With the flat side of the squeegee, push the residue to one area for removal and disposal.
- **Clean daily** or at the end of each shift.
 - Do not step on the mat until it is completely dry.

